

# BemaGhost

---



# BemaGhost

Software destinado a remoção de drivers Bematech instalados no equipamento do cliente.

Permite a remoção de drivers fiscais, não fiscais e da porta serial virtual (Bematech Virtual Serial Port).

Interface de remoção através de parâmetros de chamada ou por opção de menu.

O BemaGhost além de desinstalar o driver, remove o device e libera a porta de comunicação (no caso de porta serial virtual) para o Sistema Operacional.

Deve ser executado com privilégios de administrador!

SOLUÇÕES INTELIGENTES PARA O SEU NEGÓCIO

[www.bematech.com.br](http://www.bematech.com.br)



bematechsa



bematech s/a




bematech s/a



## Modo de usar

- 1 – MP-2100 TH FI
- 2 – MP-3000 TH FI
- 3 – MP-4000 TH FI
- 4 – MP-7000 TH FI
- 5 – MP-4200 TH FI
- 6 – MP-4200 TH FI II
- 7 – RB-1000 FI
- 8 – MP-4000 TH
- 9 – MP-4200 TH
- 10 – MP-2500 TH
- 11 – Virtual Serial Port
- 12 – Drivers Fiscais (Abrange as opções 1 até 7)
- 13 – Drivers Não Fiscais (Abrange as opções 8 até 10)
- 99 – Todos os drivers Bematech



The screenshot shows a Windows application window titled "C:\Users\b1104119\Desktop\BemaDrivers\BemaGhost\Release\BemaGhost.exe". The application displays a menu titled "BemaGhost" with the following options:



- 1 - Remove drivers MP-2100 TH FI
- 2 - Remove drivers MP-3000 TH FI
- 3 - Remove drivers MP-4000 TH FI
- 4 - Remove drivers MP-7000 TH FI
- 5 - Remove drivers MP-4200 TH FI
- 6 - Remove drivers MP-4200 TH FI II
- 7 - Remove drivers RB-1000 FI
- 8 - Remove drivers MP-4000 TH
- 9 - Remove drivers MP-4200 TH
- 10 - Remove drivers MP-2500 TH
- 11 - Remove driver Virtual Serial Port
- 12 - Remove drivers fiscais
- 13 - Remove drivers nao fiscais
- 99 - Remove todos drivers Bematech

Below the menu, it says "Digite a opcao desejada: \_".

SOLUÇÕES INTELIGENTES PARA O SEU NEGÓCIO

# Exemplo

```
----- BemaGhost -----
1 - Remover drivers MP-2100 TH FI
2 - Remover drivers MP-3000 TH FI
3 - Remover drivers MP-4000 TH FI
4 - Remover drivers MP-7000 TH FI
5 - Remover drivers MP-4200 TH FI
6 - Remover drivers MP-4200 TH FI II
7 - Remover drivers RB-1000 FI
8 - Remover drivers MP-4000 TH
9 - Remover drivers MP-4200 TH
10 - Remover drivers MP-2500 TH
11 - Remover driver Virtual Serial Port
12 - Remover drivers fiscais
13 - Remover drivers nao fiscais
99 - Remover todos drivers Bematech
-----
Digite a opcao desejada: 9_
```



SOLUÇÕES INTELIGENTES PARA O SEU NEGÓCIO

[www.bematech.com.br](http://www.bematech.com.br)



bematechsa



bematech s/a



bematech s/a



# Modo de usar

1 – Através de parâmetros de chamada:

Ex:

BemaGhost.exe 9 – Remove drivers da MP-4200 TH.

BemaGhost 12 – Remove todos os drivers fiscais.

2 – Através de escolha por menu

Ex:

BemaGhost.exe - <Enter> - Digite a opção desejada: 2 - <Enter> - Remove drivers da MP-3000 TH FI.

BemaGhost.exe - <Enter> - Digite a opção desejada: 7 - <Enter> - Remove drivers do RB-1000 FI.

SOLUÇÕES INTELIGENTES PARA O SEU NEGÓCIO

[www.bematech.com.br](http://www.bematech.com.br)



bematechsa



bematech s/a



bematech s/a

